


Model No.:

Air Ratchet Wrench ARW-127



Model No.:

Air Ratchet Wrench ARW-127



MODEL ARW-127 Air Ratchet Wrench

INDEX	PART NO.	DESCRIPTION	INDEX	PART NO.	DESCRIPTION
1	BFR1270201001	HOUSING	23	BFR1270201023	IDLER GEAR PIN
2	BFR1270201002	VALVE PLUG	24	BFR1270201024	CLAMP NUT
3	BFR1270201003	O-RING	25	BFR1270201025	BUSHING
4	BFR1270201004	SPRING	26	BFR1270201026	RATCHET HOUSING
5	BFR1270201005	ROLL PIN	27	BFR1270201027	PIN
6	BFR1270201006	O-RING	28	BFR1270201028	NEEDLE BEARING
7	BFR1270201007	SPRING PIN	29	BFR1270201029	CRANK SHAFT
9	BFR1270201009	THROTTLE LEVER	30	BFR1270201030	DRIVE BUSHING
10	BFR1270201010	END PLATE CAP	31	BFR1272010311	RATCHET YOKE
11	BFR1270201011	REAR BEARING	32	BFR1270201032	RATCHET ANVIL (1/2")
12	BFR1270201012	REAR PLATE	33	BFR1270201033	SPRING
13	BFR1270201013	ROTOR BLADE	34	BFR1270201034	WASHER
14	BFR1270201014	ROTOR	35	BFR1270201035	THRUST WASHER (1/2")
15	BFR1270201015	CYLINDER PIN	36	BFR1270201036	RETAINER RING
16	BFR1270201016	CYLINDER	37	BFR1270201037	RATCHET PAWL
17	BFR1270201017	FRONT PLATE	38	BFR1270201038	LOCK PIN
18	BFR1270201018	FRONT BEARING	39	BFR1270201039	SPRING
19	BFR1270201019	WASHER	40	BFR1272010401	REVERSE BUTTON
20	BFR1270201020	THREAD RING GEAR	41	BFR1270201041	CONNECTION HEAD
21	BFR1270201021	IDLER GEAR	42	BFR1270201042	STEEL BALL
22	BFR1270201022	IDLER GEAR PLATE			