


Model No.:

Air Riveter AR-6302



Model No.:

Air Riveter AR-6302



MODEL AR-6302 Air Riveter

INDEX	PART NO.	DESCRIPTION	INDEX	PART NO.	DESCRIPTION
1C	6302R01	3/16" NOSEPIECE	26	6302R26	PISOTN HEAD LOCK SCREW
1A	6302R01-1	1/8" NOSEPIECE	27	6302R27	PLUNGER ROD
1B	6302R01-2	5/32" NOSEPIECE	28	6302R28	O-RING SEAL
2	6302R02	HEAD	29	6302R29	DAMPING RING
3	6302R03	JAW HOUSING	30	6302R30	TRIGGER ARM
4	6302R04	JAWS	31	6302R31	AIR CYLINDER BODY
5	6302R05	JAW PUSHER	32	6302R32	ROLL PIN
6	6302R06	SPRING	33	6302R33	SPRING
7	6302R07	NUT	34	6302R34	AIR CYLINDER CAP
8	6302R08	JAW HOUSING CUPLER	35	6302R35	O-RING -VALVE TUBE
9	6302R09	WIPER RING	36	6302R36	VALVE SPRING
10	6302R10	O-RING SEAL	37	6302R37	VALVE PLATE
11	6302R11	O-RING WASHER	38	6302R38	VALVE PRESSURE SPRING
12	6302R12	HYDRAULIC SECTION	39	6302R39	O-RING SEAL
13	6302R13	O-RING SEAL	40	6302R40	WRENCH
14	6302R14	HYDRAULIC PLUNGER	41	6302R41	SCREW PLUG
15	6302R15	O-RING SEAL	42	6302R42	O-RING WASHER
16	6302R16	O-RING WASHER	43	6302R43	SEALING WASHER
17	6302R17	O-RING SEAL	44	6302R44	1/4" AIR INLET FITTING (F)
18	6302R18	HYDRAULIC RETURN SPRING	0	6302R46	1/4" AIR INLET FITTING (M)
19	6302R19	HYDRAULIC ROD GUIDE	45	6302R45	AIR INLET PLUG
20	6302R20	LOCK NUT	46	6302R46	WASHER SEAL
21	6302R21	SCREW PLUG	47	6302R47	HAND GRIP
22	6302R22	FRONT PISTON HEAD DISC	48	6302R48	PLASTIC BOTTLE
23	6302R23	PISTON HEAD PACKING RING	49	6302R49	VALVE TUBE
24	6302R24	REAR PISTON HEAD DISC	50	6302R50	RUBBER CUSHION
25	6302R25	PISTON HEAD SPRING WASHER	-	6302R51	WRENCH (14mm)