


Model No.:

Air Drill 1/2" ADR-130R



Model No.:

Air Drill 1/2" ADR-130R



MODEL ADR-130R 1/2" Air Drill

INDEX	PART NO.	DESCRIPTION	INDEX	PART NO.	DESCRIPTION
1	BFD130R406001	HOUSING MOTOR	21	BFD130R408002	INTERNAL GEAR
2	BFD130RS20560	CYLINDER PIN	22	BFD130R408004	GERA
3	BFD130R406034	AIR INLET	23	BFD130R201023	PIN
4	BFD130R406019	TRIGGER	24	BFD130R408003	GEAR PLATE
5	BFD130R406012	VALVE STEM	25	BFD13R3010301	BALL BEARING
6	BFD130R406014	REVERSE BUSHING	26	BFD13R2010181	BALL BEARING
7	BFD130R201006	O-RING	27	BFD130R405027	CHUCK-SCREW
8	BFD130R406008	SPRING	28	BFD130R406015	O-RING
9	BFD130R406010	O-RING	29	BFD130R406035	EXHAUST DIFFUSER
10	BFD130R406016	REVERSE LEVER	30	BFD130R401028	SCREW
11	BFD130R402011	MOTOR GASKET	31	BFD130R408006	CLAMP NUT
12	BFD130R401025	SET SCREW	32	BFD130R404030	1/2" CHUCK
13	BFD13R2010111	BALL BEARING	33	BFD130R170027	WASHER
14	BFD130R406003	REAR END PLATE	34	BFD130R408005	PLANET LIN SPINDLE
15	BFD130R406005	CYLINDER	35	BFD130RP40082	CHUCK KEY
16	BFD130R201013	ROTOR BLADE	36	BFD130RBCU405	RING HAND
17	BFD130R406033	SPRING PIN	37	BFD130RBBP405	HAND GRIP
18	BFD130R408001	ROTOR	38	BFD130R312032	O-RING
19	BFD130R406009	FRONT PLATE	39	BFD130RBGP405	HAND GRIP SEAT
20	BFD13R4010161	BALL BEARING			