


Model No.:
Reversible Angle Air Drill ADR-100AM



Model No.:

Reversible Angle Air Drill ADR-100AM



MODEL ADR-100AM Reversible Angle Air Drill					
INDEX	PART NO.	DESCRIPTION	INDEX	PART NO.	DESCRIPTION
1	B100AM2150101	MOTOR HOUSING	28	B100AM2150228	ROTOR
2	B100AM2150102	REVERSE BUSHING	29	B100AM3121217	ROTOR BLADE
3	B100AM2150103	REVERSE SPRING	30	B100AM2150230	FRONT END PLATE
4	B100AM2150104	REVERSE VALVE	31	B100AM00B2208	BALL BEARING
5	B100AM2150105	VALVE BUSHING	32	B100AM2160332	PLANET GEAR
6	B100AM2150106	THROTTLE VALVE	33	B100AM3160329	PLANET PIN
7	B100AM00RX006	O-RING	34	B100AM2150334	CAGE
8	B100AM00RX008	O-RING	35	B100AM2150335	GEAR SPINDLE
9	B100AM3121105	VALVE SPRING	36	B100AM2150336	INTERNAL GEAR
10	B100AM00R0802	O-RING	37	B100AM2150337	SPACER
11	B100AM2150110	REVERSE RETAINER	38	B100AM00B2812	BALL BEARING
12	B100AM2150112	VALVE SCREW	39	B100AM2150339	FPINION
13	B100AM2150113	HOUSING GASKET	40	B100AM2150340	HOUSING LOCK RING
14	B100AM2150114	HOUSING CAP	41	B100AM2150341	ANGLE HOUSING
15	B100AM00P2522	SPRING PIN	42	B100AM2150342	SET SCREW
16	B100AM00R0902	O-RING	43	B100AM3130326	OIL PLUG
17	B100AM2150118	HOUSING CAP STOP WASHER	44	B100AM2150344	RETAINING RING
18	B100AM2150116	DEFLECTOR	45	B100AM2150346	SPINDLE GEAR
19	B100AM00R1202	O-RING	46	B100AM00B1907	BALL BEARING
20	B100AM2150120	INLET BUSHING	47	B100AM2150348	BEARING CASE
21	B100AM2150121	THROTTLE LEVER	48	B100AM2150349	SPINDLE GEAR
22	B100AM00P0322	SPRING PIN	49	B100AM3130332	WOODRULFKEY
23	B100AM2150223	MOTOR GASKET	50	B100AM2150351	RETAINING RING
24	B100AM00B1906	BALL BEARING	51	B100AM2125321	3/8" DRILL CHUCK
25	B100AM2150225	REAR END PLATE	52	B100AM2150352	CHUCK SCREW
26	B100AM2150226	MOTOR PIN		B100AM00WO318	SK4 SPANNER WRENCH
27	B100AM2150227	CYLINDER			