


Model No.:

Adjustable Clutch Air Screw Driver ASD-404LN



Model No.:

Adjustable Clutch Air Screw Driver ASD-404LN



MODEL ASD-404LN Adjustable Clutch Air Screw Driver

INDEX	PART NO.	DESCRIPTION	INDEX	PART NO.	DESCRIPTION
1	01-102-03	ROTOR BALDE	29	17-302-02	SWITCH LEVER
2	02-200-07	O-RING (P8×1.5)	30	18-702-01	REVERSE VALVE
3	02-201-10	O-RING (P15.5×1.5)	31	19-702-02	SPEED SWITCH
4	02-202-03	O-RING (P29.87×1.8)	32	21-502-01	WASHER
5	03-700-02	STEEL BALL (Ø2.5mm)	33	24-302-01	VALVE ROD
6	03-700-03	IRON BALL (Ø3.175mm)	34	24-705-02	VALVE ROD
7	03-700-04	STEEL BALL (Ø4mm)	35	25-702-08	AIR INLET (PT)
8	03-700-07	STEEL BALL (Ø3.175mm)	36	26-703-06	MUFFLER
9	04-700-03	PIN (Ø2×6)	37	31-703-01	HOOK
10	04-701-02	PIN (Ø4×13)	38	35-706-09	ROTOR
11	04-701-04	PIN (Ø2×14)	39	36-503-07	FRONT PLATE
12	04-702-04	PIN (Ø3×24)	40	37-503-02	RERA PLATE
13	05-701-05	PIN (Ø2×14)	41	38-503-01	CYLINDER
14	06-700-01	SPRING	42	39-701-10	BOLT
15	06-700-05	SPRING	43	48-704-01	GEAR RING
16	06-701-13	SPRING	44	49-702-02	GEAR SEAT
17	06-701-26	SPRING	45	51-501-02	BUSHING
18	08-707-01	SPRING	46	51-702-02	BUSHING
19	10-701-01	STOPPING WHEEL (Ø10mm)	47	51-802-01	BUSHING
20	11-702-01	RETAINING RING	48	52-301-01	WASHER
21	12-700-06	RETAINING RING	49	52-700-01	WASHER
22	13-700-03	SCREW	50	52-701-02	WASHER
23	13-702-01	SCREW	51	52-702-01	WASHER
24	15-701-07	BALL BEARING (626)	52	73-502-01	CLUTCH
25	15-702-02	BALL BEARING (608)	53	74-704-07	DRIVING ROD
26	15-702-10	BALL BEARING (6001)	54	74-705-11	ANVIL
27	15-703-01	BALL BEARING (6201)	55	75-607-06	FRONT CAP
28	16-701-04	GEAR	56	79-608-01	HANDLE