


Adjustable Clutch Air Screw Driver ASD-405LN



Model No.:

Adjustable Clutch Air Screw Driver ASD-405LN



MODEL ASD-405LN Adjustalbe Clutch Air Screw Driver

INDEX	PART NO.	DESCRIPTION	INDEX	PART NO.	DESCRIPTION
1	01-102-03	ROTOR BALDE	29	18-702-01	REVERSE VALVE
2	02-200-07	O-RING (P8×1.5)	30	19-702-02	SPEED SWITCH
3	02-201-10	O-RING (P15.5×1.5)	31	21-502-01	WASHER
4	02-202-03	O-RING (P29.87×1.8)	32	24-302-01	VALVE ROD
5	03-700-02	STEEL BALL (Ø2.5mm)	33	24-705-02	VALVE ROD
6	03-700-03	IRON BALL (Ø3.175mm)	34	25-702-08	AIR INLET (PT)
7	03-700-04	STEEL BALL (Ø4mm)	35	26-703-06	MUFFLER
8	03-700-07	STEEL BALL (Ø3.175mm)	36	31-703-01	HOOK
9	04-700-03	PIN (Ø2×6)	37	35-706-02	ROTOR
10	04-701-04	PIN (Ø2×14)	38	36-503-17	FRONT PLATE
11	04-701-05	PIN (Ø4×15)	39	37-503-02	RERA PLATE
12	04-702-04	PIN (Ø3×24)	40	38-503-01	CYLINDER
13	05-701-05	PIN (Ø2×14)	41	39-701-11	BOLT
14	06-700-01	SPRING	42	48-703-01	GEAR RING
15	06-700-05	SPRING	43	49-502-02	GEAR SEAT
16	06-701-26	SPRING	44	51-501-01	BUSHING
17	06-703-01	SPRING	45	51-606-01	BUSHING
18	08-707-01	SPRING	46	51-701-04	BUSHING
19	11-702-01	RETAINING RING	47	51-702-02	BUSHING
20	12-700-06	RETAINING RING	48	51-802-01	BUSHING
21	13-700-03	SCREW	49	52-301-01	WASHER
22	13-702-01	SCREW	50	52-701-02	WASHER
23	15-701-07	BALL BEARING (626)	51	52-702-02	WASHER
24	15-702-04	BALL BEARING (R6)	52	73-702-01	CLUTCH
25	15-703-01	BALL BEARING (6201)	53	74-706-02	ANVIL
26	16-701-02	GEAR	54	74-706-07	DRIVING ROD
27	16-701-08	GEAR	55	75-607-06	FRONT CAP
28	17-302-02	SWITCH LEVER	56	79-608-01	HANDLE